


## Instructions for Verichron World Time Clock

The Verichron World Time Clock shows both local time and times at major cities around the world.



- 1) Set the hands of the clock to your local time using the time set knob on back.
- 2) Use a small screwdriver to turn the World Time Disc on the back side of the clock, so that your local time on the 24-hour band of the clock face lines up with your time zone. Note that hours on the disc run 0 through 24, so that 1PM = 13 hours, 2PM = 14 hours, midnight = 24 hours.
3. If the clock runs fast or slow, use a small screwdriver to adjust the speed setting. Make adjustments in small increments. It may take several attempts to regulate the movement.

*Note: The clock movement is mechanical. The 1.5 volt D cell winds the main spring in the clock movement every 8 minutes.*